



Instructions for unpacking booms.

1. Unhook coiled rope from the Gooseneck.




2. Remove shackle from Gooseneck.
3. Lay on the deck as shown.



Instructions for packing boom at end of sailing day.


1. Snap the boom out of the mast.
2. Close the shackle at end of mainsheet.
3. Lay on the deck as shown.




4. Bring block with Shackle to gooseneck and hook over it.





5. Grab outhaul ( thin rope) to pull system to end of boom.




6. Go back to the gooseneck end of the boom. Grab both ropes as close as possible to the end. Make loops to end of both ropes.



7. Grab one of the earlier loops. Wrap this one around close to the top a few times, then tuck in through the top.



8. Hook this loop over the gooseneck.



9. Pack it neatly on the shelf to the left of the doorway.